

SAFETY INSTRUCTIONS

compliant with GPSR

Product: PLATINUM garden furniture set - sofa, 2 chairs and table with glass top

Manufacturer: Texcorp Sp. z o.o.

Address: ul. Głogowska 31/33, 60-702 Poznań, Polska

Contact e-mail: office@texcorp.pl

Contact phone: +48 728 976 693

1. Product description

The PLATINUM garden furniture set is intended for outdoor and domestic use, especially in the garden, on a terrace, balcony, patio or in a gazebo. The set consists of a two-seater sofa, two garden chairs, a garden table with a graphite tempered glass top and 4 cushions with backrests.

The seats are made of plastic - polypropylene with a woven texture, and the frame is made of metal/steel. The cushions are intended for seasonal use; they are water-resistant, UV-resistant and easy to clean.

The product is intended only for sitting and for recreational use of the table. Do not use any part of the set as a ladder, platform, toy or structural element.

2. Technical and usage parameters

- Set components: 2 garden chairs, 2-seater sofa, garden table, 4 cushions with backrests
- Frame colour: graphite
- Cushion pattern: green grass
- Maximum load of one chair: 120 kg
- Maximum sofa load: 200 kg
- Maximum table load: 50 kg
- Table top: graphite, made of tempered glass
- Seat material: plastic, polypropylene with a woven texture
- Frame material: steel
- Use: garden, terrace, balcony, patio, gazebo
- Assembly: self-assembly, instructions included
- Additional tools: not required
- Total set weight: approx. 36 kg
- Resistance to UV, moisture and frost when used correctly

3. Method of use

- Before first use, assemble all elements according to the included assembly instructions.
- Connect all parts securely and tighten the screws only after the structure has been correctly positioned.
- Place the furniture on an even, stable and hard surface.
- Before each use, check that the chairs, sofa and table are stable and have no damaged parts.
- Do not exceed the maximum loads: chair 120 kg, sofa 200 kg, table 50 kg.
- Place the cushions securely so that they do not move during use.
- Do not sit or stand on the table. The table is intended only for placing light items within the permitted load.
- After the season or during a longer break in use, store the cushions in a dry place.

4. Precautions

- The product is not a toy. Do not allow children to climb, jump or swing on any part of the set.
- Children should use the product only under adult supervision.
- Do not sit on armrests, backrests, chair edges, sofa edges or on the table.
- Do not stand on the chairs, sofa or table and do not use them as a platform.
- Do not exceed the maximum load: chair 120 kg, sofa 200 kg, table 50 kg.
- Before use, make sure that all assembly parts are correctly tightened.
- Do not use the product if the frame, seat, backrest, top, armrests or assembly parts are cracked, deformed or damaged.
- Protect the tempered glass top from strong impacts, falling heavy or sharp objects and sudden temperature changes.
- If the glass cracks or chips, stop using the table immediately.
- Place the product away from open flames, grills, fire pits, garden fireplaces and other sources of high temperature.
- Protect the cushions from prolonged contact with heavy rain, standing water and moisture.
- Dry wet cushions before storage to reduce the risk of mould and unpleasant odours.

5. Assembly

The set is intended for self-assembly. Assembly must be carried out according to the instructions included with the set.

During assembly, it is recommended to first connect all parts loosely and tighten the screws only after the structure has been correctly positioned. Incorrect assembly may affect product stability and user safety.

After assembly, check that all connections are stable and that the furniture stands evenly on the ground.

6. Cleaning and maintenance

- Clean the furniture and cushions with a soft, damp cloth.
- Do not use aggressive detergents, solvents, bleach or sharp cleaning tools.
- Clean the glass top carefully using a soft cloth and products intended for glass if necessary.
- In most cases, dirt on the cushions can be removed with a damp cloth.
- After cleaning, leave the product to dry completely.
- Store the cushions in a dry and ventilated place, especially outside the season.
- Regularly check the screws and assembly connections. Tighten them if necessary.
- For longer storage, protect the product from dirt, moisture and mechanical damage.

7. Warnings

WARNING! Chairs and sofa are intended only for sitting. Do not use as a ladder, platform or toy.

WARNING! Do not exceed the maximum loads: chair 120 kg, sofa 200 kg, table 50 kg.

WARNING! Do not sit or stand on the table. The table top is made of tempered glass.

WARNING! Do not use the product if it is damaged, unstable or incomplete.

WARNING! Keep the product away from fire and sources of high temperature.

WARNING! Be careful during assembly - there is a risk of trapping fingers.

8. Packaging warning

WARNING! Plastic packaging may pose a suffocation hazard.

Do not allow children or animals to play with plastic film, bags or packaging elements. After unpacking, keep packaging out of reach of children and animals or dispose of it immediately in accordance with

local regulations.

9. Disposal

Dispose of the product and its packaging in accordance with local waste regulations. Elements made of plastic, metal, glass, cardboard or film should be sorted according to local municipal rules.

Do not discard the product or its components in the natural environment.

10. Safety and GPSR compliance

The product is intended for normal use according to its function. To maintain safety, follow these instructions, assembly recommendations and warnings.

If you notice product damage or any hazard related to its use, stop using the product and contact the manufacturer.