

Safety Instructions – Garden Chair Cushion

IMPORTANT SAFETY INFORMATION

1. Product purpose

The cushion is intended for use on garden chairs as an element that increases seating comfort. The product can be used in the garden, on a terrace, balcony, and in other outdoor spaces. The cushion is not a toy and should not be used by children for play. The product is intended only for use in accordance with its function – as a seat and backrest cushion.

2. Technical parameters and material

- Product: garden chair cushion.
 - Cover: waterproof fabric.
 - The fabric has anti-UV properties, helping to reduce colour fading and maintain the product's appearance for several seasons.
 - Filling: soft filling that increases seating comfort.
 - The product is equipped with ties / fastening straps that help secure the cushion to the chair.
 - The product is made of safe and non-toxic materials.
 - The product does not contain SVHC substances in concentrations above 0.1%.
-

3. Safe use instructions

- Before use, make sure that the cushion is properly positioned on the chair.
 - The cushion should be attached to the chair using ties / straps, if the product is equipped with them.
 - Use only on stable and properly positioned garden chairs.
 - Do not use the cushion as a mattress, toy, protective pad or impact-absorbing element.
 - Do not stand on the cushion or use it as a platform.
 - Do not use the product if the material is torn, the seams are damaged or the filling is coming out.
 - During heavy rain, storms, hail or frost, it is recommended to store the cushion in a dry place.
 - Despite its waterproof properties, the product should not be left for long periods in standing water or constant moisture.
-

4. Cleaning and maintenance

- Clean by hand with a soft, damp cloth.
- In case of dirt, use lukewarm water and a mild detergent.
- Do not use aggressive chemicals, bleach or solvents.
- Do not machine wash unless otherwise stated by the manufacturer on the product label.
- Do not tumble dry.

- Do not iron.
 - Dry thoroughly before storage to prevent mould and unpleasant odours.
-

5. Warnings

- ⚠ The product is intended exclusively as a garden chair cushion.
 - ⚠ The product is not a toy – keep away from children without supervision.
 - ⚠ Do not use near open flames or sources of high temperature.
 - ⚠ Do not use the product if the material, seams, ties or filling are damaged.
 - ⚠ A wet cushion may increase the risk of slipping – before use, make sure the product is stable and properly positioned.
 - ⚠ Do not leave the product unsecured in strong wind conditions.
-

6. Packaging information

- The product is packed in plastic packaging to protect it during transport.
 - ⚠ The plastic film is not a toy – there is a risk of suffocation.
 - Keep the packaging away from infants and children.
 - After unpacking, dispose of the plastic film immediately or send it for recycling.
-

7. Disposal

- The product and its packaging should be disposed of through selective collection of textile and plastic waste.
 - Do not dispose of with household waste.
 - Dispose of worn or damaged products in accordance with local waste management regulations.
-

8. Safety and compliance with regulations

The product complies with the requirements of Regulation (EU) 2023/988 (GPSR) on general product safety.

The product is safe to use in accordance with its intended purpose and made of materials intended for contact with the user.

The product does not contain harmful substances in concentrations above the permitted limits.

Manufacturer / Distributor:

TEXCORP Sp. z o.o.

Głogowska 31/33

60-702 Poznań, Poland

E-mail: office@texcorp.pl

Phone: +48 728 976 693